



Position	Code	description
	ES0061431	Bellow bottle 702 cpl
03	FL300123410	SIDES RIGHT LEFT
05	FL300128	COVER
07	FL93449	ASS. TANK
08	FL93443	TRAY
09	FL93448	CUP PLATE
10	FL93447	GRID
11	FL93445	CAPSULES CONTAINER
12	FL300210	KIT LEVER
13	FL300137	HANDLE
14	FL18911	SCREW
15	FL300203N	INFUSOR
16	FL300127	COVER
17	FL300201	DISTRIBUTOR
18	FL3002051	CC SLEEVE ORING TB ASM 230V (NORIBS)
19	FL29145	CONNECTOR
21	FL3003301	PUMP
22	FL29907	O-RING
23	FL300311	CONNECTOR
24	FL18280	FILTER
25	FL300312	PUMP CONNECTOR
30	FL391101	BOARD ASSEMBLY
31	FL39202	PUSH BUTTON
32	FL29905	STOP
33	FL300431	POWER SUPPLY CORD
34	FL17002	FLOWMETER