





Position	Code	description
	6113210021	CLIP
	5313242131	COFFEE OUTLET
	5313242321	GASKET
	ES0061431	Bellow bottle 702 cpl
01	7313234671	WATER TANK
02	5313242061	REAR PANEL
03	5313238171	PUSH BUTTON
04	5313242021	SIDE LEFT
05	5313230221	RUBBER PAD
06	5013211891	POWER SUPPLY CORD
07	7313234701	PIPETTE
08	5313242031	SIDE RIGHT
09	5513221691	STOP
10	5313242141	COVER COFFEE OUTLET
11	7313234791	COVER ASSEMBLY
12	7313234811	CONTAINER ASSEMBLY
13	7013212131	CUP PLATE
14	5313238001	DRIP TRAY
15	5313239981	FLOAT
20	7313235291	CONTROL PANEL ASSEMBLY
21	5213216991	BOARD
22	5113211161	MICROSWITCH
23	5313238231	SUPPORT MICROSWITCH
24	5313226361	PIN
25	6113210851	SPRING
26	5313239991	STOPPER
27	5213216961	POWER BOARD
28	5213217281	SENSOR REED
29	5513217751	TUBE PTFE DI2-DE4 L=120 2BUSHES
30	5313217701	O-RING D=3,85
31	7313234681	COUPLING CARAFE
32	5313235381	ASPIRATION TUBE
33	7313232921	CARAFE ASSEMBLY
34	5313220031	O-RING
35	5513216561	TUBE FEP DI2-DE4 L=230 2BUSHES
36	5313228791	GASKET
37	7313244961	ASSEMBLY TMBU

38	7313221911	EXPANSION CHAMBER
39	5332154600	TUBE (SIL NAT) DI=7 L=70
40	5313225291	PUMP TUBE
41	7313222431	SAFETY VALVE
42	5213218371	SOLENOID VALVE
43	5513216521	TUBE PTFE DI2-DE4 L=205 2BUSHES
44	5213218261	SOLENOID VALVE CEME 5330VN2
45	6132101300	CLIP
46	5313210371	PUMP CONNECTOR
47	5332144800	O-RING D=6
49	5013255251	WIRING TCO
50	5113210411	PUMP
51	5513217171	TUBE FEP DI2-DE4 L=95 2BUSHES
52	5013254891	WIRING
53	5213214671	FLOWMETER
54	5313234391	FILTER
55	5313226561	FLOWMETER TUBE
57	5213218151	SENSOR NTC
58	5513216551	TUBE FEP DI2-DE4 L=85 2BUSHES
59	5332239200	CONNECTOR
60	5313228791	GASKET
61	5332239300	SPACER 5XD5.2XD7.9 NATURAL
62	5013254681	WIRING TCO
63	5013254691	WIRING TCO
64	5513220541	GENERATOR
65	5513216741	STEAM CONNECTOR
66	5213215191	TCO
67	5513228041	VAPORIZER
68	5313235831	CONNECTOR